

→ **Book of Parameters**  
Speedy 100, 60 watt

## Content

<b>1 General information</b> .....	<b>3</b>
1.1 "Quality" vs. "Speed" optimized parameters.....	3
1.2 Machinery and job setup used for parameter finding .....	3
1.3 General recommendations .....	3
1.4 Individual parameter fine tuning .....	3
<b>2 TroLase</b> .....	<b>4</b>
<b>3 TroLase Metallic</b> .....	<b>4</b>
<b>4 TroLase Metallic Plus</b> .....	<b>5</b>
<b>5 TroLase Reverse</b> .....	<b>5</b>
<b>6 TroLase Thins</b> .....	<b>6</b>
<b>7 TroLase ADA Signage</b> .....	<b>6</b>
<b>8 TroLase Textures</b> .....	<b>7</b>
<b>9 TroGlass</b> .....	<b>7</b>
<b>10 TroGlass Clear</b> .....	<b>8</b>
<b>11 MarkSolid</b> .....	<b>8</b>
<b>12 Anodized Aluminium / Aluminium eloxiert</b> .....	<b>9</b>
<b>13 LaserFlex</b> .....	<b>9</b>
<b>14 MDF</b> .....	<b>9</b>
<b>15 Plywood / Speerholz</b> .....	<b>10</b>
<b>16 Solid Wood / Vollholz</b> .....	<b>11</b>
<b>17 Veneered Wood / Furniertes Holz</b> .....	<b>12</b>

## 1 General information

JobControl<sup>®</sup> features parameters for Trotec laser materials. The book of parameters is offering supplementary advice as to how these new parameters can be used.

Engraving and cutting results always depend on the equipment used, specific applications, as well as the requirements regarding quality and productivity. By providing two different parameter sets "Quality" and "Speed" we are covering a wide range of conditions. Feedback and suggestions will help us to further develop these parameters and are highly appreciated.

### 1.1 "Quality" vs. "Speed" optimized parameters

"Quality" parameter sets are recommended for applications where fine detail and strong contrast is required.

"Speed" parameters are for time-efficiency orientated applications, where a reduced degree of detail in engraving is acceptable.

### 1.2 Machinery and job setup used for parameter finding

- Speedy 100
- Atmos Duo exhaust system
- Ferro-magnetic table plus honeycomb
- 2" lens unless stated otherwise
- Air assist on, lower pressure and wide nozzle recommended for improved results. Check lens regularly for cleanness.
- Engraving over the whole working area with multiple rectangular engraving jobs
- "Speed" jobs are printed to JobControl<sup>®</sup> with 333 DPI unless stated otherwise; "Quality" jobs are printed to JobControl<sup>®</sup> with 600 DPI unless stated otherwise.

### 1.3 General recommendations

- Engraving is recommended to be carried out from the bottom to the top, preventing residue from being pulled over freshly engraved parts on route to the exhaust, resulting in a cleaner engraving.
- Air assist is enabled ("On").  
Laser Correction (LC-value) is set to 10
- Accurate focus is prerequisite for good engraving and cutting results (controlled de-focus through Z-offset). Please make sure the material stays flat over the whole working area.

### 1.4 Individual parameter fine tuning

Depending on a specific application, minor adjustments of standard settings may allow for improved quality or reduced engraving time. For this, step-by-step adjustments in the range of +/- 10 % are recommended on power, speed and DPI.

#### → **Tips:**

- Increasing the Z-Offset (controlled de-focus) can allow for an increased contrast and a darker engraving image. However, this may also result in a decrease of detail engraving.
- Increasing the laser pulse rate (Hz) when cutting can allow for a cleaned, flame polished edge, especially for transparent materials.
- Turning off the air assist in Job Control can improve results for engravings where high quality is a priority. In this case check lens more often for cleanness.

## 2 TroLase

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	65%	70%	600	1	On	+1 mm (0.040")
Cut 0.8mm (1/32")	40%	2%	1000	1	On	0
Cut 1.6mm (1/16")	50%	0.8%	1000	1	On	0
Cut 3.2mm (1/8")	70%	0.8%	1000	1	On	-1.6mm (1/16")

Print DPI: 600

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	85%	100%	500	1	On	+1 mm (0.040")
Cut 0.8mm (1/32")	80%	5%	1000	1	On	0
Cut 1.6mm (1/16")	100%	1.6%	1000	1	On	0
Cut 3.2mm (1/8")	100%	1%	1000	1	On	-1.6mm (1/16")

Print DPI: 333

## 3 TroLase Metallic

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	80%	100%	600	1	On	+1 mm (0.040")
Cut 0.8mm (1/32")	40%	1.5%	1000	1	On	0
Cut 1.6mm (1/16")	45%	0.8%	1000	1	On	0
Cut 3.2mm (1/8")	100%	0.7%	1000	1	On	-1.6mm (1/16")

Print DPI: 600

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	85%	100%	500	1	On	+1 mm (0.040")
Cut 0.8mm (1/32")	80%	4.5%	1000	1	On	0
Cut 1.6mm (1/16")	90%	1.6%	1000	1	On	0
Cut 3.2mm (1/8")	100%	1%	1000	1	On	-1.6mm (1/16")

Print DPI: 333

#### 4 TroLase Metallic Plus

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	50%	90%	600	1	On	+1 mm (0.040")
Cut 0.8mm (1/32")	40%	1.5%	1000	1	On	0
Cut 1.6mm (1/16")	45%	0.8%	1000	1	On	0
Cut 3.2mm (1/8")	100%	0.7%	1000	1	On	-1.6mm (1/16")

**Print DPI: 600**

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	70%	100%	500	1	On	+1 mm (0.040")
Cut 0.8mm (1/32")	80%	4.5%	1000	1	On	0
Cut 1.6mm (1/16")	90%	1.6%	1000	1	On	0
Cut 3.2mm (1/8")	100%	1%	1000	1	On	-1.6mm (1/16")

**Print DPI: 333**

#### 5 TroLase Reverse

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	100%	50%	600	1	On	+2,5mm (0.1")
Cut 1.6mm (1/16")	90%	1%	1000	1	On	0

**Print DPI: 600**

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	100%	50%	500	1	On	+2,5mm (0.1")
Cut 1.6mm (1/16")	90%	2%	1000	1	On	0

**Print DPI: 333**

## 6 TroLase Thins

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	50%	90%	600	1	On	+1 mm (0.040")
Cut 0.5mm (0.02")	25%	1.5%	1000	1	On	0

**Print DPI: 600**

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	100%	100%	500	1	On	+1 mm (0.040")
Cut 0.5mm (0.02")	25%	2%	1000	1	On	0

**Print DPI: 333**

## 7 TroLase ADA Signage

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Cut 0.8mm (1/32")	50%	2%	1000	1	On	0
Cut 1.0mm (0.040")	60%	2%	1000	1	On	0
Cut 1.6mm (1/16")	45%	1%	1000	1	On	0
Cut 3.2mm (1/8")	65%	0.6%	1000	1	On	0

**Print DPI: 1000**

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Cut 0.8mm (1/32")	65%	2.5%	1000	1	On	0
Cut 1.0mm (0.040")	65%	2%	1000	1	On	0
Cut 1.6mm (1/16")	72%	1.5%	1000	1	On	0
Cut 3.2mm (1/8")	65%	0.6%	1000	1	On	0

**Print DPI: 1000**

## 8 TroLase Textures

→ Quality	Lens	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	2.5"	100%	25%	600	1	On	0
Cut 1.6mm (1/16")	2.5"	70%	0.7%	1000	1	On	0
Cut 3.2mm (1/8")	2.5"	100%	0.4%	1000	1	On	0

**Print DPI: 600**

→ Speed	Lens	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	2.5"	100%	30%	333	1	On	0
Cut 1.6mm (1/16")	2.5"	100%	1%	1000	1	On	0
Cut 3.2mm (1/8")	2.5"	100%	0.6%	1000	1	On	0

**Print DPI: 333**

## 9 TroGlass

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	26%	20%	500	1	On	0
Cut 3mm (0.118")	95%	0.5%	5000	1	On	0

**Print DPI: 500**

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	28%	20%	500	1	On	0
Cut 3mm (0.118")	95%	0.8%	1000	1	On	0

**Print DPI: 333**

## 10 TroGlass Clear

→ Quality	Lens	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	2.0"	26%	20%	500	1	On	0
Cut 3mm (0.118")	2.0"	95%	0.5%	20.000	1	On	-1.0mm (0.040")
Cut 4mm (0.167")	2.0"	95%	0.4%	20.000	1	On	-1.2mm (3/64")
Cut 5mm (0.208")	2.0/2.5"	90%	0.2%	20.000	1	On	-1.5mm (1/16")

Print DPI: 333

→ Speed	Lens	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	2.0"	28%	20%	500	1	On	0
Cut 3mm (0.118")	2.0"	95%	0.8%	20.000	1	On	-1.0mm (0.040")
Cut 4mm (0.167")	2.0"	95%	0.5%	20.000	1	On	-1.2mm (3/64")
Cut 5mm (0.208")	2.0/2.5"	95%	0.4%	20.000	1	On	-1.5mm (1/16")

Print DPI: 333

## 11 MarkSolid

→ Quality	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	40%	20%	500	1	On	0

Print DPI: 500

→ Speed	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Engrave	90%	50%	500	1	On	0

Print DPI: 500



## 12 Anodized Aluminium / Aluminium eloxiert

→ <b>GLOSS</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Quality engraving	80%	50%	600	1	On	0
Speed engraving	100%	50%	500	1	On	+1 mm (0.040")

**Print DPI: 600**

**Print DPI: 333**

→ <b>MATT</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Quality engraving	60%	50%	600	1	On	0
Speed engraving	90%	50%	500	1	On	+1 mm (0.040")

**Print DPI: 600**

**Print DPI: 333**

## 13 LaserFlex

→ <b>All Colors</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Standard engraving	58%	50%	600	1	On	0
Large engraving	60%	50%	500	1	On	0
Cut	12%	1%	1000	1	On	0

**Print DPI: 500/600**

## 14 MDF

→ <b>Panel 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	45%	50%	500	1	On	0
Dark engraving	65%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	90%	0.9%	1000	1	On	0

**Print DPI: 500**

→ <b>Panel 6mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail Engrave	45%	50%	500	1	On	0
Dark Engrave	65%	50%	500	1	On	+6mm (0.24")
Cut 6mm (0.24")	90%	0.2%	1000	1	On	0

**Print DPI: 500**

**15 Plywood / Speerholz**

→ Panel 3mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	80%	100%	500	1	On	0
Dark engraving	100%	100%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	95%	2%	1000	1	On	0

**Print DPI: 500**

→ Panel 6mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	80%	100%	500	1	On	0
Dark engraving	100%	100%	500	1	On	+6mm (0.24")
Cut 6mm (0.24")	95%	0.7%	1000	1	On	0

**Print DPI: 500**



**16 Solid Wood / Vollholz**

→ Alder / Erle 3mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	80%	50%	500	1	On	0
Black engraving	85%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	65%	1%	1000	1	On	0

→ Alder / Erle 5mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	80%	50%	500	1	On	0
Black engraving	85%	50%	500	1	On	+6mm (0.24")
Cut 5mm (0.208")	95%	0.8%	1000	1	On	0

→ Cherry/Kirsch 5mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	70%	50%	500	1	On	0
Black engraving	85%	50%	500	1	On	+6mm (0.24")
Cut 5mm (0.208")	95%	0.6%	1000	1	On	0

→ Maple / Ahorn 5mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	80%	50%	500	1	On	0
Black engraving	90%	50%	500	1	On	+6mm (0.24")
Cut 5mm (0.208")	95%	0.6%	1000	1	On	0

→ Oak / Eiche 5mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	75%	50%	500	1	On	0
Black engraving	80%	50%	500	1	On	+6mm (0.24")
Cut 5mm (0.208")	95%	0.5%	1000	1	On	0

→ Walnut / Walnuss 5mm	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	80%	50%	500	1	On	0
Black engraving	90%	50%	500	1	On	+6mm (0.24")
Cut 5mm (0.208")	95%	0.5%	1000	1	On	0

**Print DPI: 500**

**17 Veneered Wood / Furniertes Holz**

→ <b>Maple/Ahorn 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	55%	50%	500	1	On	0
Black engraving	75%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	70%	0.7%	1000	1	On	0

→ <b>Bamboo/Bambus 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	50%	50%	500	1	On	0
Black engraving	65%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	70%	0.7%	1000	1	On	0

→ <b>Birch/Birke 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	60%	50%	500	1	On	0
Black engraving	80%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	70%	0.7%	1000	1	On	0

→ <b>Cherry/Kirsche 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	55%	50%	500	1	On	0
Black engraving	75%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	70%	0.8%	1000	1	On	0

→ <b>Walnut/Walnuss 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	65%	50%	500	1	On	0
Black engraving	80%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	70%	0.8%	1000	1	On	0

→ <b>Cedar/Zeder 3mm</b>	Power	Speed	PPI / HZ	Passes	Air Assist	Z-Offset
Detail engraving	50%	50%	500	1	On	0
Black engraving	70%	50%	500	1	On	+6mm (0.24")
Cut 3mm (0.118")	70%	0.7%	1000	1	On	0

**Print DPI: 500**

